



## AUTO DRY CABINET FOR CONTROL HUMIDITY STORAGE



**Anti-ESD**

**Non-ESD**



**Display panel**

### Features

1. LED display, imported humidity sensor with error of  $\pm 3\%RH$ .
2. Quality 1mm and 1.2mm cold rolled plate, reinforced structure design, high intensity bearing, every shelf can bear over 100kg.
3. Using 3.2mm toughened glass.
4. Zinc alloy lock with plus pressure capability.
5. RoHs certified powder coating technology with Dupont powder, high anti-erosion performance to avoid your stored goods from pollution and static shock.
6. AC power 85V~265V 50/60Hz.
7. Smart control system and resettable target humidity

Relative Humidity	Suitable items for storage
A/60~50%RH	Paintings, antiques, paper money, old books, fax paper, copy paper
A/50~30%RH	Cameras, CD, LD technical drawing, lenses, microscopes, magnetic tapes, musical instruments, leather goods, etc.
A/30~20%RH	Precision dies, measurement instruments, normal PCB, semiconductors and etc.
B/20~10%RH	IC, BGA, lead free PCB, measuring tools, precision electronic parts and etc
C/10~1%RH	Material that is typically sensitive to humidity, e.g, high precision IC, BGA, silver articles, copper articles and etc.
U/5~1%RH	Extremely humidity sensitive device with materials that are likely to go oxidized like silver, brass, bronze, tungsten, etc and nitrogen condition is recommended most often



## Technical Data

Capacity	Non-ESD	Anti-ESD	Controlled Humidity (RH)	Outer Size (WxDxH mm)	Inner Size (WxDxH mm)
98L	HA98-2060	HA98E-2060	20-60%	448 x 400 x 688	448 x 372 x 598
	HB98-1020	HB98E-1020	10-20%		
	HC98-0110	HC98E-0110	1-10%		
	HU98-0105	HU98E-0105	1-5%		
160L	HA160-2060	HA160E-2060	20-60%	448 x 450 x 1010	448 x 422 x 848
	HB160-1020	HB160E-1020	10-20%		
	HC160-0110	HC160E-0110	1-10%		
	HU160-0105	HU160E-0105	1-5%		
240L	HA240-2060	HA240E-2060	20-60%	598 x 400 x 1310	596 x 372 x 1148
	HB240-1020	HB240E-1020	10-20%		
	HC240-0110	HC240E-0110	1-10%		
	HU240-0105	HU240E-0105	1-5%		
320L	HA320-2060	HA320E-2060	20-60%	900 x 450 x 1010	898 x 422 x 848
	HB320-1020	HB320E-1020	10-20%		
	HC320-0110	HC320E-0110	1-10%		
	HU320-0105	HU320E-0105	1-5%		
435L	HA435-2060	HA435E-2060	20-60%	900 x 600 x 1010	898 x 572 x 848
	HB435-1020	HB435E-1020	10-20%		
	HC435-0110	HC435E-0110	1-10%		
	HU435-0105	HU435E-0105	1-5%		
540L	HA540-2060	HA540E-2060	20-60%	598 x 710 x 1465	596 x 682 x 1298
	HB540-1020	HB540E-1020	10-20%		
	HC540-0110	HC540E-0110	1-10%		
	HU540-0105	HU540E-0105	1-5%		
718L	HA718-2060	HA718E-2060	20-60%	598 x 710 x 1910	596 x 682 x 1723
	HB718-1020	HB718E-1020	10-20%		
	HC718-0110	HC718E-0110	1-10%		
	HU718-0105	HU718E-0105	1-5%		
870L	HA870-2060	HA870E-2060	20-60%	900 x 600 x 1890	898 x 572 x 1698
	HB870-1020	HB870E-1020	10-20%		
	HC870-0110	HC870E-0110	1-10%		
	HU870-0105	HU870E-0105	1-5%		
1436L	HA1436-2060-4/6	HA1436E-2060-4/6	20-60%	1200 x 710 x 1910	1198 x 682 x 1723
	HB1436-1020-4/6	HB1436E-1020-4/6	10-20%		
	HC1436-0110-4/6	HC1436E-0110-4/6	1-10%		
	HU1436-0105-4/6	HU1436E-0105-4/6	1-5%		